

# 2D point spread function characterization for Prime Focus Spectrograph

N. Caplar, J. Meyers, R. Lupton, J. Gunn, PFS collaboration







PRINCETON  
UNIVERSITY



# 3 components to the PSF

- Telescope pupil illumination
- Focal ratio degradation in the fibres
- Spectrograph cameras







## 3 components to the PSF

- Telescope pupil illumination
- Focal ratio degradation in the fibres
- Spectrograph cameras

- Separate these 3 components (vignetting, fibers & camera) causing aberrations in the PSF by working in wavefront space
- We aim to characterize contribution of camera imperfections to PSF by modelling optical performance using defocussed data






Wavelength






Different fibers

Wavelength








Different fibers



## How to decouple the illumination and the wavefront aberrations?


- Images at different value of defocus
- Follow wavefront aberrations as a function of defocus



More defocused

In focus



More defocused







## Wavefront aberrations as function of defocus (Zemax)

- We wish to deduce/reproduce these curves from the data
- Model wavefront aberrations at each position in the detector





## Defocused data, example in linear space




## Defocused data, example in log space




## Defocused data, example in log space









- Example from modelling of the experimental data below  
(not the same spot as above!)




# Change of single component – (vertical astigmatism)







Changing defocus

## Direct Fits



Residuals scaled to  
5% of the maximal flux  
in the data



Speckles – can be  
“removed” by fitting  
higher order  
wavefront  
abberations


## Direct Fits

Up to z22

Up to z254

Residuals scaled to  
5% of the maximal flux  
in the data





Perfection







High order  
abberations do not  
vary as a position of  
the detector? (if they  
come from glass  
imperfections)

Speckles – can be  
``removed" by fitting  
higher order  
wavefront  
abberations

Focused  
data,  
example in  
linear space




Focused  
data,  
example in  
log space




# Residuals in the focused data, 8 different dithering positions






Residuals, up to Zernike 22 and Jan 15 modifications to centering



# Residuals in the focused data, 8 different dithering positions, after Random forest cleaning applied

up to Zernike 22, Jan 15 modifications to centering, and Random Forest postprocessing





# Why do we keep asking for more data with different settings?

22 | 2 | 2D pipeline development and support      Thursday, February 7th

 **Robert Lupton** 5:02 PM  
I'm missing something. We need the `pfsConfig` file for the cable-B config  
`expId`.

 **Craig Loomis** 5:02 PM  
`pfsDesign`s will be fixed. I think we can probably freeze those to `pfsConfigs` with visit=lowNumber

 **Paul Price** 5:03 PM  
A `PfsConfig` is an implementation of a `PfiDesign` for a particular exposure.

 **Craig Loomis** 5:03 PM  
umm, a particular `visit0` (and up), right?  
 1

 **Robert Lupton** 5:03 PM  
Or add a fallback to the `PfiDesign` if the `PfsConfig` is unavailable.

 **Paul Price** 5:05 PM  
That seems reasonable. We're not using the `pfiCenter` values from the `PfsConfig` yet...

 **Robert Lupton** 5:06 PM  
Right.


 **Paul Price** 5:07 PM  
Do we have a header keyword specifying the `pfiDesignId`, `@cloomis`?

 **Craig Loomis** 5:08 PM  
yes, I think so. One sec.

 **Paul Price** 5:09 PM  
My code is looking for `W_PFDGN`.

 **Craig Loomis** 5:09 PM  
That sounds right.

 **Paul Price** 5:09 PM  
Is it going to be set in data coming from LAM?



Every new dataset  
presents a new  
challenge

# Why do we keep asking for more data with different settings?

★ | 8 22 | 2 2D pipeline development and support

Monday, April 29th

 **Fabrice Madec** 10:57 AM  
yes that's for new data  
  
I tried: ingestPfsImages.py /drp/fmadec/ --mode=link /drp/fmadec/pfiDesign-0x0000000000000000.fits -c clobber=True  
register.ignore=True

 **Neven Caplar** 10:58 AM  
nope!!!!  
  
do not ingest pfiDesign  
that will fail  
  
you can ingest all \*.fits as I did  
pfiDesign will connect

10:59 AM so just ingest everything and do not worry about failures of ingesting pfiDesign files

 **Fabrice Madec** 10:59 AM  
so we have to put the pfiDesign file in the raw directory

 **Neven Caplar** 10:59 AM  
that is what I am doing ([@paulprice](#)?)


 **Paul Price** 10:59 AM  
The ingest script looks in the raw directory for the pfsDesign files.  
(The pfsDesign files should be alongside the raw images.)

 1

You don't need to refer to the pfsDesign files at all: they will be picked up automatically. It's the images that you want to ingest.

s/don't need to/shouldn't/

 **Fabrice Madec** 10:59 AM



Every new dataset  
presents a new  
challenge


 DRP 2-D Pipeline / PIPE2D-414

reduceExposure.doSubtractContinuum=True does not remove continuum fro

[Edit](#) [Comment](#) [Assign](#) [More ▾](#) [In Progress](#) [In Review](#) [Workflow ▾](#)

## Mercury - Argon

## Krypton



DRP 2-D Pipeline / PIPE2D-415

Sometimes pfsArm has less elements than number of fibers in the image

[Edit](#) [Comment](#) [Assign](#) [More ▾](#) [In Progress](#) [In Review](#) [Workflow ▾](#)

### Details

Type:	<input checked="" type="checkbox"/> Bug	Status:	<a href="#">OPEN</a> ( <a href="#">View Workflow</a> )
Priority:	<input type="checkbox"/> Normal	Resolution:	Unresolved
Affects Version/s:	None	Fix Version/s:	None
Labels:	None		
Story Points:	4		
Sprint:	2DDRP-2019 E	<a href="#">Edit</a>	

I. Different data (various arcs and fibers) are testing our pipeline

### Description

Possibly closely connected with [PIPE2D-414](#).


[naoki.yasuda](#) reports in [PIPE2D-339](#) that ``But for visit=14000 only a half of fibers will be identified (left hand side)``. This is probably the same problem as I report from Krypton data e.g., visit 13052, in [PIPE2D-411](#). There should be 16 fibers but

```
butler_KrFeb = Butler("/tigress/ncaplar/ReducedData/KrFeb_2019/rerun/Apr30_2019/arc")
arc = butler_KrFeb.get("pfsArm", visit=13052, arm="r", spectrograph=1)
```


## II. Why different arcs?

- a) To span the full focal plane
- b) To check consistency of the results

Neon





HgAr



## II. Why different arcs?


- a) To span the full focal plane
- b) To check consistency of the results





## II. Why different arcs?

- a) To span the full focal plane
- b) To check consistency of the results

Neon






### III. Why focused data?




a) Scattering, scattering...

### III. Why focused data?




a) Scattering, scattering...  
b) Grating effects



## IV. Why different stops?


a) only illumination of the full pupil gives full information



Mistakes in the non-illuminated region!

## IV. Why different stops?

a) only illumination of the full pupil gives full information



b) experiment for the quality of the approach

Mistakes in the non-illuminated region!

## Summary

- 3 components to the PSF
  - Telescope pupil illumination
  - Focal ratio degradation in the fibres
  - Spectrograph cameras
- Characterize contribution of camera imperfections to PSF by modelling optical performance using defocussed data
- Defocused images on both sides of focus should allow to decouple the illumination and the wavefront abberations
- What do we use different data for
  - Testing the pipeline
  - Different arcs to fill up the plane
  - Defocused and focused data to test different properties
  - Different stops change the illumination of the pupil